



REQUIRED HARDWARE

- Construction Adhesive
- Finishing Nails
- Nails
- Drill Bit
- Screws

REQUIRED TOOLS

- Bevel Square
- Hammer
- Glue Gun
- Level
- Saw
- Drill

INSTALLATION INSTRUCTIONS

STEP 1

Remove any carpeting and all nails and staples.

STEP 2

Cut off the front of each plywood stair nosing, flush to the riser.

STEP 3

Measure and cut riser using bevel square.

STEP 4

Apply construction adhesive to back of riser and faster firmly with finishing nails.

STEP 5

Measure and cut tread to fit.

STEP 6

Apply construction adhesive, fasten with nails or screws, and make sure tread is level.

STEP 7

Install remaining risers and treads following the same pattern.

Qwik and Easy to Install
Remodeling or New Stairs

Kit Includes:

- Qwik Tread 48"
- Returned Ends
- Riser (Wood 1-S, Primed 1-S)



Available in Red Oak or
Maple

The Fastest Staircase Makeover

12 1/2" Depth

- Allows Trimming to Fit
- A Majority of Tread Widths

8-Ply Solid Core

- Plywood w/thick hardwood top veneer
- No cupping, lays Flat!



Mitered returned both sides allow you to cut off one end to make LH or RH without assembly